


Arrow Springs



MANUAL **Voltage & Amperage Adaptor**

Voltage & Amperage Adaptors allow you to operate a 240 volt oven using a 120 volt temperature controller.

The adaptor has a plug and receptacle to match the 240 volt oven you want to control. Plug the adaptor's 240 volt plug into an appropriate wall receptacle. Plug the oven's 240 volt plug into the matching receptacle on the adaptor.

The adaptor also has a 120 volt plug. Plug that into the receptacle of your existing 120 volt temperature controller.

Be sure to move the temperature controller's thermocouple to the oven that it is controlling.

Instead of the temperature controller directly controlling a 120 volt oven, it controls the adaptor, which in turn controls a 240 volt oven. The 240 volt oven receives its 240 volt power from the adaptor, which in turn receives its power from the 240 volt wall receptacle.

Manufacturer and Supplier to the Flameworking Industry
4301 A Product Drive Shingle Springs, CA 95682
Phone: (800) 899-0689 Fax: (530) 677-1600
flameon@ArrowSprings.com www.ArrowSprings.com